## **INSTALLATION INSTRUCTIONS**


Turn fixture off! (Place wall switch in off position, if fixture has built-in switch or chain pull, switch or pull chain so fixture is off.)




Next - go to the main fuse box. If ■ your fuse box has an ON/OFF switch, Screw-in type fuses - unscrew the fuse simply place main power switch in or fuses that control the power to the OFF position.




fixture or room you are working in.




CONNECT THE WIRES. NOTE: Attach black fixture wire to black supply wire, white fixture wire to white supply wire. Do not mix them up. Use approved electrical tape or wire connectors (not provided). Connect bare fixture ground wire to ground wire from outlet box, NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES.



SLIP ONE HINGE PIN on roof into hole in socket on cage and snap other hinge into open socket.



INSTALL PLASTIC PANELS, textured or beveled side out, by sliding panels down cage in slots on inside of cage. Make sure panels are all the way down into seats in cage.



set screw (not provided)

POSITION THE FIXTURE over the post as shown. For permanent mounting, fasten with set screw at hole in post collar by drilling hole at same location through post and securing with screw.

CAUTION: Do not turn on without diffuser

### installed. Do not touch LEDs or circuit board. LED optics could be damaged. No lamp replacement required! Integral LED light engine supplied. Do not remove protective cover from LED light engine.



Clean only with mild soap and water. Avoid spraying with cleansers, insecticides, and pesticides that are petroleum based hydrocarbon products. These will degrade Luminaire.

# **INSTALLATION INSTRUCTIONS**




Turn fixture off! (Place wall switch in off position, if fixture has built-in switch or chain pull, switch or pull chain so fixture is off.)




Next - go to the main fuse box. If ■ OFF position.




your fuse box has an ON/OFF switch, Screw-in type fuses - unscrew the fuse simply place main power switch in or fuses that control the power to the fixture or room you are working in.



CONNECT THE WIRES. NOTE: Attach black fixture wire to black supply wire, white fixture wire to white supply wire. Do not mix them up. Use approved electrical tape or wire connectors (not provided). Connect bare fixture ground wire to ground wire from outlet box. NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES.



SLIP ONE HINGE PIN on roof into hole in socket on cage and snap other hinge into open socket.



INSTALL PLASTIC PANELS, textured or beveled side out, by sliding panels down cage in slots on inside of cage. Make sure panels are all the way down into seats in cage.



set screw (not provided)

POSITION THE FIXTURE over the post as shown. For permanent mounting, fasten with set screw at hole in post collar by drilling hole at same location through post and securing with screw.

CAUTION: Do not turn on without diffuser installed. Do not touch LEDs or circuit board. LED optics could be damaged. No lamp replacement required! Integral LED light engine supplied. Do not remove protective cover from LED light engine.



Clean only with mild soap and water. Avoid spraying with cleansers, insecticides, and pesticides that are petroleum based hydrocarbon products. These will degrade Luminaire.

1270TLEOS 1270TLEOS